



CXN IR Remote Control Codes

v1.0

*All codes are RC-5.
System code 24 or 28 (switchable within CXN Settings menu)*

Function	Decimal command code
More	09
Home	12
Up	13
Left	16
Select/Enter	17
Right	18
Down	19
Random	20
Repeat	21
Return	22
Skip Left	23
Play/Pause	24
Skip Right	25
Stop	27
Info	28
Bluetooth	31
USB Audio	32
D1	35
D2	36
1	57
2	58
3	59
4	60
5	61
6	62
7	63
8	64
Digital Input Menu	120



The following commands are also supported:

System code 25

Function	Decimal command code
Power Toggle	12
Power On	14
Power Off	15
LCD Bright	18
LCD Dim	19
LCD Off	71
Brightness Toggle	72

Because other CX products (eg. CXA amplifier) will also respond to the above system code 25 power commands, the following CXN power command is also supported:

System code 24

Function	Decimal command code
Power Toggle	02

The following codes are also supported when the CXN is in Digital Pre-amp mode:

System code 16

Function	Decimal command code
Mute toggle	13
Vol +	16
Vol -	17

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to contact us at: <http://support.cambridgeaudio.com/>

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright Cambridge Audio Ltd 2015