



Azur 651A/C IR Remote Control Codes

651C CD Commands

System Code = 20 (RC-5 Code)

Key	Command Code dec
Open/Close	45
CD Player on	50
CD Player off	51
Power toggle	12 (not implemented on r/c)
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	14
0	0
Prog	36
AB	59
Skip left	33
Play	53
Skip right	32
<<	44
Stop	54
>>	43
Info	21
Pause	48
LCD Bright	40
Remain	61
Random	28
Repeat	29
LCD All segments On/Off	57



651A Amplifier Commands

System Code = 16 (RC-5 Code)

Key	Command Code dec
Source Up	8
Speaker Select	20
S1	2
S2	5
S3	3
S4	1
S5	4
USB	0
Vol +	16
Vol -	17
Mute on	50
Mute off	51
Power toggle	12 (not implemented on r/c)
Amp on	14
Amp off	15

Also incorporates Apple iPod codes

System Code = EE 87 (NEC Code)

BUTTON	SET 1 (xx odd parity UID)	SET 2 (xx even parity UID)
Menu (Stop)	EE 87 02 xx	EE 87 03 xx
Play/Pause (Pause Button)	EE 87 5E xx	EE 87 5F xx
Select (Play Button)	EE 87 5D xx	EE 87 5C xx
Vol Up	EE 87 0B xx	EE 87 0A xx
Vol Down	EE 87 0D xx	EE 87 0C xx
Skip Left	EE 87 08 xx	EE 87 09 xx
Skip Right	EE 87 07 xx	EE 87 06 xx

NOTE: Commands from either SET1 or SET2 are sent depending on the current UID (last byte of the command). The UID is a unique ID used by slave device to pair to a remote control. On reset UID for all source buttons are set to 00.