

Topaz AXR85/100 Stereo Receiver Remote Control Codes

All Codes are NEC format.

(NEC Code)

Remote Button	IR Code
standby	C0 3F 06 F9
Mute	C0 3F 00 FF
Speaker A/B	C0 3F 1A E5
Stereo/Mono (Tuner)	C0 3F 19 E6
Mode (Tuner)	C0 3F 18 E7
Volume Up	C0 3F 1D E2
Skip/Scan down (Tuner)	C0 3F 1E E1
Menu	C0 3F 5A A5
Skip/Scan up (Tuner)	C0 3F 1C E3
Volume Down	C0 3F 5E A1
Preset 1/5	C0 3F 03 FC
Preset 2/6	C0 3F 40 BF
Preset 3/7	C0 3F 42 BD
Preset 4/8	C0 3F 41 BE
D1	C0 3F 17 E8
D2	C0 3F 54 AB
D3	C0 3F 55 AA
A1	C0 3F 1B E4
A2	C0 3F 58 A7
A3/AUX	C0 3F 59 A6
PHONO	C0 3F 1F E0
Bluetooth	C0 3F 5C A3
FM/AM	C0 3F 5D A2

