



Evo 75 & Evo 150 IR Remote Control Codes

All Codes are RC5 format.

Function	System Code	Command Code
Power toggle	16	12
Mute toggle	16	13
Volume Up	16	16
Volume Down	16	17
Output Select	16	20
Display Brightness	16	72
Next Source	16	8
Previous Source	16	9
i	24	28
Play/Pause	24	24
Skip Back	24	23
Skip Forward	24	25
Preset 1	24	57
Preset 2	24	58
Preset 3	24	59

The Evo unit will also respond to the following commands that are not on the supplied Remote Control.

Function	System Code	Command Code
Power On	16	14
Power Off	16	15
Mute	16	50
Unmute	16	51
Source Aux	16	100
Source Coax	16	105
Source Optical	16	106
Source Bluetooth	16	115
Source TV ARC	16	7
Source CD	16	121
Source Balanced (Evo 150 only)	16	104
Source Phono (Evo 150 only)	16	103
Source Optical 2 (Evo 150 only)	16	107
Source USB Audio (Evo 150 only)	16	114

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to contact us at: <http://support.cambridgeaudio.com/>

© Copyright Cambridge Audio Ltd 2021